**YOW SKU # 691 603**

**Model # TY325-1514-0**

# USE AND CARE GUIDE

## 4 ft 9 in Lighted Tinsel Santa in Car with Gift Box

*THANK YOU*

We appreciate the trust and confidence you have placed in Home Accents through the purchase of this 4 ft 9 in Lighted Tinsel Santa in Car with Gift Box. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Accents!

### Guarantee

#### What is Covered

The product is intended for residential seasonal use for approximately 90 days per year. This product is covered by a 90 day limited guarantee due to defects in material and workmanship. Return the product with purchase receipt to the location of purchase for refund within 90 days of purchase.

#### What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDs, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, misuse or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday

**1-877-527-0313**
**HOMEACCENTSHOLIDAY.COM**

# Pre-Assembly

## PLANNING ASSEMBLY

Carefully remove all the parts from the box, and place them on a flat surface. Read the entire manual prior to assembly and identify all the parts included in the package against the parts list. If any parts are missing or damaged do not attempt assembly. Contact our customer service center or return with proof of purchase. Assembly of this product may require more than one person.

## PACKAGE CONTENTS




| Package Contents/Parts List | | |
|---|---|---|
| Part | Description | Quantity |
| A | Big Giftbox | 1 |
| B | Small Giftbox | 1 |
| C | Rear of Car | 1 |
| D | Candy Cane | 1 |
| E | Santa's and Cockpit | 1 |
| F | Front of Car | 1 |
| G | Rear-View Mirror | 2 |

| Package Contents/Parts List | | |
|---|---|---|
| Part | Description | Quantity |
| H | Wreath | 1 |
| I | Head light | 2 |
| J | Wheels | 4 |
| K | Ground Stakes | 4 |
| L | Spare Fuse | 2 |
| M | Spare Bulb | 10 |
| N | Plastic Tie | 10 |

# Assembly

## Assembling the Santa in Car With Gift Box




FIG.1

Step 1. Unfold the Big and Small Gift Boxes (A&B) then attached the stabilizing bar into the matching hole on the closest side to form the Giftbox. Unfold the Rear of Car (C) and insert the hook into the matching hole on the closest side to form the Rear of Car. (FIG.1)




FIG.2

Step 2. Insert the metal rods attached to each Wheel (J) into the matching holes on the underside of the Rear of Car (C) and Front of Car (F). Insert Giftboxes (A&B) and Candy Cane (D) into the matching holes on the Rear of Car (C). (FIG.2)
Step 3. Insert the metal rod on the Santa and Cockpit (E) into the holes on the top of the Front of Car. Insert the rod of Rear-View Mirrors (G) into the matching holes at the front left and right side of the Santa and Cockpit (E). (FIG.2)
Step 4. Insert both Head Lights (I) and Wreath (H) into the matching holes at the frontside of the Front of Car (F). Insert the metal rods to the Rear of Car (C) into the matching holes in the Front of Car (F) then fasten with Plastic Ties (N) to create a Car. (FIG.2)

FIG.3

Step 5. Secure the Car to the ground by using the Ground Stakes (K). (FIG.3)

# Pre-Operation

**CAUTION:** Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

**CAUTION:** The lighting string on this product is rated at 122.4 Watts (1.02Amps). Do not overload. Do not connect to other lighting strings, decorative outfit or other electrical products. Before you use or re-use this product inspect it carefully. Return to Store or discard if the product has cuts, damage or frayed wire insulation on cords, cracks in the socket enclosures, loose connections or exposed copper wire.

# Care and Cleaning

a. Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product, wire and lighting connections. If the product is placed somewhere other than the ground it should be well secured and stable.
b. Wipe the unit with a damp cloth and allow the unit to dry before storing.
c. Store the product neatly in a cool, dry location protected from sunlight.

**FOR INDOOR AND OUTDOOR USE**